

Panasonic[®]

Operating Instructions

Digital Cordless Phone

Model No. **KX-TGE210HK**
KX-TGE212HK



Model shown is TGE210.

***Before initial use, see “Getting Started”
on page 8.***

Thank you for purchasing a Panasonic product.

Please read these operating instructions before using the unit and save them for future reference.

Table of Contents

Introduction

Model composition	3
Accessory information	3

Important Information

For your safety	5
Important safety instructions	6
For best performance	6
Other information	7
Specifications	7

Getting Started

Setting up	8
Controls	10
Display icons	11
Turning the power on/off	12
Language setting	12
Date and time	12
Other settings	12

Making/Answering Calls

Making calls	14
Answering calls	14
Useful features during a call	15
Handset locator	16
Intercom	16
Key lock	17
Power back-up operation	17

Phonebook

Phonebook	19
Speed dial	20

Programming

Menu list	22
Alarm	26
Do not disturb mode	26
Nuisance call block	27
Baby monitor	28
Other programming	30

Caller ID Service

Using Caller ID service	32
Caller list	32

Useful Information

Voice mail service	34
Character entry	34
Error messages	36

Troubleshooting	36
-----------------------	----

Index

Index	40
-------------	----

Model composition

Series	Model No.	Base unit	Handset	
		Part No.	Part No.	Quantity
KX-TGE210 series	KX-TGE210	KX-TGE210HK	KX-TGEA20HK	1
	KX-TGE212	KX-TGE210HK	KX-TGEA20HK	2


Accessory information

Supplied accessories

No.	Accessory item/Part number	Quantity	
		KX-TGE210	KX-TGE212
①	AC adaptor for base unit/PNLV226E	1	1
②	Telephone line cord	1	1
③	Rechargeable batteries*1	2	4
④	Handset cover*2	1	2
⑤	Belt clip	1	2
⑥	Charger	—	1
⑦	AC adaptor for charger/PNLV233E	—	1

*1 See page 4 for replacement battery information.

*2 The handset cover comes attached to the handset.



Additional/replacement accessories

Please contact your nearest Panasonic dealer for sales information.
For enquiry, please call hotline 2313 0666.

Introduction

Accessory item	Model number
Rechargeable batteries	HHR-4MY*1
	Battery type: <ul style="list-style-type: none">– Nickel metal hydride (Ni-MH)– 2 x AAA (R03) size for the handset
Headset	RP-TCA400, RP-TCA430
DECT repeater	KX-A405

*1 Replacement batteries may have a different capacity from that of the supplied batteries.

Other information

- Design and specifications are subject to change without notice.
- The illustrations in these instructions may vary slightly from the actual product.

For your safety

To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product.

WARNING

Power connection

- Use only the power source marked on the product.
- Do not overload power outlets and extension cords. This can result in the risk of fire or electric shock.
- Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire.
- Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.
- Unplug the product from power outlets if it emits smoke, an abnormal smell, or makes an unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact an authorised service centre.
- Unplug from power outlets and never touch the inside of the product if its casing has been broken open.
- Never touch the plug with wet hands. Danger of electric shock exists.

Installation

- To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture.
- Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

- Do not allow the AC adaptor or telephone line cord to be excessively pulled, bent or placed under heavy objects.

Operating safeguards

- Unplug the product from power outlets before cleaning. Do not use liquid or aerosol cleaners.
- Do not disassemble the product.
- Do not spill liquids (detergents, cleansers, etc.) onto the telephone line cord plug, or allow it to become wet at all. This may cause a fire. If the telephone line cord plug becomes wet, immediately pull it from the telephone wall jack, and do not use.
- Do not place a handset on the base unit with the headset jack cover opened.

Medical

- Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. (The product operates in the frequency range of 1.88 GHz to 1.90 GHz, and the RF transmission power is 250 mW (max.).)
- Do not use the product in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

CAUTION

Installation and location

- Never install telephone wiring during an electrical storm.
- Never install telephone line jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- The AC adaptor is used as the main disconnect device. Ensure that the AC

Important Information

outlet is installed near the product and is easily accessible.

- This product is unable to make calls when:
 - the handset batteries need recharging or have failed.
 - there is a power failure.
 - the key lock feature is turned on.

Battery

- We recommend using the batteries noted on page 4. **USE ONLY rechargeable Ni-MH batteries AAA (R03) size.**
- Do not mix old and new batteries.
- Do not open or mutilate the batteries. Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte is toxic and may be harmful if swallowed.
- Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets, or keys to touch the batteries, otherwise a short circuit may cause the batteries and/or the conductive material to overheat and cause burns.
- Charge the batteries provided with or identified for use with this product only, in accordance with the instructions and limitations specified in this manual.
- Only use a compatible base unit (or charger) to charge the batteries. Do not tamper with the base unit (or charger). Failure to follow these instructions may cause the batteries to swell or explode.

Important safety instructions

When using your product, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Do not use this product near water for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS

For best performance

Base unit location/avoiding noise

The base unit and other compatible Panasonic units use radio waves to communicate with each other.

- For maximum coverage and noise-free communications, place your base unit:
 - at a convenient, high, and central location with no obstructions between the handset and base unit in an indoor environment.
 - away from electronic appliances such as TVs, radios, personal computers, wireless devices, or other phones.
 - facing away from radio frequency transmitters, such as external antennas of mobile phone cell stations. (Avoid putting the base unit on a bay window or near a window.)
- Coverage and voice quality depends on the local environmental conditions.
- If the reception for a base unit location is not satisfactory, move the base unit to another location for better reception.

Environment

- Keep the product away from electrical noise generating devices, such as fluorescent lamps and motors.
- The product should be kept free from excessive smoke, dust, high temperature, and vibration.
- The product should not be exposed to direct sunlight.
- Do not place heavy objects on top of the product.
- When you leave the product unused for a long period of time, unplug the product from the power outlet.

- The product should be kept away from heat sources such as radiators, cookers, etc. It should not be placed in rooms where the temperature is less than 0 °C or greater than 40 °C. Damp basements should also be avoided.
- The maximum calling distance may be shortened when the product is used in the following places: Near obstacles such as hills, tunnels, underground, near metal objects such as wire fences, etc.
- Operating the product near electrical appliances may cause interference. Move away from the electrical appliances.

Routine care

- **Wipe the outer surface of the product with a soft moist cloth.**
- Do not use benzene, thinner, or any abrasive powder.

Other information

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Notice for product disposal, transfer, or return

- This product can store your private/confidential information. To protect your privacy/confidentiality, we recommend that you erase information such as phonebook or caller list entries from the memory before you dispose of, transfer, or return the product.

Information on Disposal in other Countries outside the European Union



These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

Note for battery removal procedure

Refer to "Battery installation" on page 8.

Specifications

- **Standard:**
DECT (Digital Enhanced Cordless Telecommunications),
GAP (Generic Access Profile)
- **Number of channels:**
120 Duplex Channels
- **Frequency range:**
1.88 GHz to 1.90 GHz
- **RF transmission power:**
Approx. 10 mW (average power per channel)
- **Power source:**
220–240 V AC, 50/60 Hz
- **Power consumption:**
Base unit:
Standby: Approx. 0.7 W
Maximum: Approx. 2.9 W
- **Operating conditions:**
0 °C–40 °C, 20 %–80 % relative air humidity (dry)
- **Dimensions:**
Base unit: Approx. 136 mm × 88 mm × 80 mm
Handset: Approx. 54 mm × 31 mm × 171 mm
- **Mass (weight):**
Base unit: Approx. 130 g
Handset: Approx. 140 g

Setting up




Connections

■ Base unit

- 1 Connect the AC adaptor to the unit by pressing the plug firmly.
- 2 Fasten the cord by hooking it.
- 3 Connect the AC adaptor to the power outlet.
- 4 Connect the telephone line cord to the unit, then to the telephone line jack until you hear a click.
- 5 A DSL/ADSL filter (not supplied) is required if you have a DSL/ADSL service.

Note:

- Use only the supplied Panasonic AC adaptor PNLV226E.
- Use only the supplied telephone line cord.




■ Charger

- 1 Connect the AC adaptor plug to the unit until you hear a click.
- 2 Connect the AC adaptor to the power outlet.


Note:

- Use only the supplied Panasonic AC adaptor PNLV233E.



Battery installation

- USE ONLY rechargeable Ni-MH batteries AAA (R03) size (A).
- Do NOT use Alkaline/Manganese/Ni-Cd batteries.
- Confirm correct polarities (+, -).




- Follow the directions on the display to set up the unit.

Battery charging

Charge for about 7 hours.

- Confirm "Charging" is displayed (A).

- When the batteries are fully charged, "Fully Charged" is displayed.



Note when setting up

Note for connections

- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floor-mounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.
- If the unit is connected to a PBX system, please contact your PBX supplier.

Note for battery installation

- Use the supplied rechargeable batteries. For replacement, we recommend using the Panasonic rechargeable batteries noted on page 4, 6.

Note for battery charging

- It is normal for the handset to feel warm during charging.
- Clean the charge contacts of the handset and base unit with a soft and dry cloth once a month. Before cleaning the unit, disconnect from power outlets and any telephone line cords. Clean more often if the unit is exposed to grease, dust, or high humidity.

Battery level

Icon	Battery level
	High
	Medium
	Low
	Needs charging.

Panasonic Ni-MH battery performance (supplied batteries)


Operation	Operating time
In continuous use	16 hours max.
Not in use (standby)	300 hours max.

Note:

- To maximise battery life, it is recommended that the handset batteries be fully discharged (used) until flashes once every few months.
- Actual battery performance depends on usage and ambient environment.

Controls

Handset



- 1 Ringer indicator
- 2 Belt clip hole
- 3 Speaker
- 4 **[+]/[-]** (▲: Volume up/down)
- 5 **[T]** (Talk)
- 6 Dial keypad
- 7 Headset jack
- 8 **[SPK]** (Speakerphone)
- 9 **[R/ECO]**
R: Recall/Flash
ECO: Eco mode shortcut key
- 10 Microphone

- 11 Receiver
- 12 Display
- 13 **[P]** (Off/Power)
- 14 **[NR]** (Smart Function Key/Noise reduction key)
NR indicator
- 15 Charge contacts

■ Control type

Ⓐ Soft keys

By pressing a soft key, you can select the feature shown directly above it on the display.


Ⓑ Navigator key

Navigator keys functions as follows.

Symbol	Meaning	
[▲]	[▲]	Up
[▼]	[▼]	Down
[◀]	[◀]	Left
[▶]	[▶]	Right

- **[▲]**, **[▼]**, **[◀]**, or **[▶]**: Scroll through various lists and items.
- **[▲]** or **[▼]** (**[▲]**): Adjust the receiver or speaker volume while talking.
- **[◀]** (Caller list): View the caller list.
- **[▶]** (Phonebook): View the phonebook entry.
- **[C]** (Redial): View the redial list.

Base unit



1 Charge contacts

2 [•••] (Locator)

Display icons

Handset display items

Item	Meaning
	Range status: The more bars visible, the closer the handset is to the base unit.
	Out of base unit range
	Security for phone calls is set to "Enhanced". (page 30)
	Paging, intercom mode*1
	Speakerphone is on. (page 14)
	The line is in use. <ul style="list-style-type: none"> When flashing slowly: The call is put on hold. When flashing rapidly: An incoming call is now being received.
	Missed call*2 (page 32)
	Eco mode is set to "Eco". (page 13)
	Noise reduction is set. (page 15)
	The LCD and key backlight is off. (page 24)
	Battery level
	Alarm is on. (page 26)
	Privacy mode is on.*1 (page 24)
	Ringer volume is off. (page 23)
	Do not disturb mode is on. (page 26)
	Nuisance call blocked.*2 (page 27)
	New voice mail message received.*3 (page 34)

Item	Meaning
	Baby monitor is activated. The name/number displayed next to the icon indicates the monitoring unit. (page 28)
Line in use	Someone is using the line.*1

*1 KX-TGE212

*2 Caller ID subscribers only

*3 Voice mail subscribers only

Handset soft key icons

Icon	Action
	Returns to the previous screen or outside call.
	Displays the menu.
	Accepts the current selection.
	Makes a call. (page 14)
	Temporarily turns off the ringer for incoming calls. (page 14)
	Places a call on hold.*1
	Opens the phonebook.
	Allows you to edit phone numbers. (page 28)
	Adds new entry. (page 20, 29)
	Displays the phonebook search menu. (page 19)
	Turns the key lock feature off. (page 17)
	Stops alarm. (page 26)
	Snooze button on the alarm. (page 26)
	Selects entries or handset. (page 12, 26)
	Stores phone numbers. (page 19)
	Erases the selected item.
	Allows you to make an intercom call.*1
	Erases a number/character.

Getting Started

Icon	Action
	Puts the call on mute.

*1 KX-TGE212

Turning the power on/off

Press for about 2 seconds.

Language setting

Display language

- 1
- 2 : Select your desired language. →
- 3

Date and time

- 1
- 2 Enter the current date, month, and year.
→
Example: 15 July, 2014
- 3 Enter the current hour and minute.
Example: 9:30
 - You can select 24-hour or 12-hour clock format ("AM" or "PM") by pressing .
- 4 →

Other settings

Smart Function Key (NR key)

The Smart Function Key (NR key) is located on the bottom of the handset and informs you with its flashing to allow you to activate the following features by simply pressing this key.

- When the NR indicator flashes rapidly, you can:
 - Answer the call (outside call, intercom*1). (page 14)
 - Stop paging.
 - Stop the alarm sound. (page 26)*1 KX-TGE212
- When the NR indicator flashes slowly in standby mode, you can:
 - View the caller list when there are missed calls. (page 32)To activate this feature, the Smart Function Key must be "On". (page 12)

Using the Smart Function Key (NR key)

When the NR indicator flashes rapidly/slowly, press .

- The above features can be activated depending the situation.
- If you answer a call using the Smart Function Key, the speakerphone is activated.
- Even if the handset is placed on the base unit, the feature can be activated. You can talk without lifting up the handset. If you want to perform further operations, lift up the handset.

Note:

- While key lock is on (page 17), incoming calls can be answered, but the following feature is disabled even when the NR indicator flashes slowly.
 - View the caller list when there are missed calls. (page 32)

Setting the Smart Function Key

The Smart Function Key for the following feature must be "On".

- "Missed Call" (Default: Off)

- 1
- 2
 - "✓" is displayed next to the selected features.
 - To cancel a selected feature, press again. "✓" disappears.

3 [OK] → [📞]

Note:

- If the **NR** indicator flashes when the handset is not placed on the base unit, battery consumption is faster than usual.

Eco mode setting

You can select the desired eco mode setting by pressing **[R/ECO]**.

The following settings are available for eco mode.

- **“Eco”**: Reduces the base unit transmission power by up to 90 % in standby mode. When this setting is selected, **ECO** is displayed on the handset display instead of **Y**.
- **“Eco Off”** (default setting): Turns off eco mode. When this setting is selected, **ECO** are not displayed in the handset display.

Note:

- When there is another cordless phone in use nearby, the base unit transmission power may not be reduced. (KX-TGE212)
- When eco mode is active, the range of the base unit is reduced in standby mode.
- If you set repeater mode to “On” (page 31):
 - Eco mode is disabled.
 - **“Eco Mode”** is not displayed in the display menu (page 23).

Dialling mode

If you cannot make calls, change this setting according to your telephone line service. The default setting is **“Tone”**.

“Tone”: For tone dial service.

“Pulse”: For rotary/pulse dial service.

- 1 [📞] (right soft key) [# 1 2 0]
- 2 [📞]: Select the desired setting.
- 3 [OK] → [📞]

Making calls

- 1 Lift the handset and dial the phone number.
 - To correct a digit, press [C].
- 2 [↶]
- 3 When you finish talking, press [📞] or place the handset on the base unit or charger.

Using the speakerphone

- 1 Dial the phone number and press [🔊].
- 2 When you finish talking, press [📞].

Note:

- To switch back to the receiver, press [🔊]/[↶].

Adjusting the receiver or speaker volume

Press [➕] or [➖] repeatedly while talking.

Making a call using the redial list

The last 10 phone numbers dialed are stored in the redial list (each 24 digits max.).

- 1 [📞]
- 2 [↕]: Select the desired entry.
- 3 [↶]

Erasing a number in the redial list

- 1 [📞]
- 2 [↕]: Select the desired entry. → [X]
- 3 [↕]: "Yes" → [OK] → [📞]

Pause (for PBX/long distance service users)

A pause is sometimes required when making calls using a PBX or long distance service. When storing a calling card access number and/or PIN in the phonebook, a pause is also needed (page 20).

Example: If you need to dial the line access number "0" when making outside calls with a PBX:

- 1 [0] → [▲] (Pause)
- 2 Dial the phone number. → [↶]

Note:

- A 3 second pause is inserted each time [▲] (Pause) is pressed.

Answering calls

When a call is being received, the ringer indicator and **NR** indicator flash rapidly.

- 1 Lift the handset and press [↶] or [🔊] when the unit rings.
- 2 When you finish talking, press [📞] or place the handset on the base unit or charger.

Any key answer: You can answer the call by pressing any dial key.

Auto talk: You can answer calls simply by lifting the handset (page 24).

Temporary handset ringer off: You can turn the ringer off temporarily by pressing [🔇].

Using the Smart Function Key

When the **NR** indicator flashes rapidly, press [NR].

- You can answer the call even if the handset is placed on the base unit or charger (page 12).
You can finish talking by pressing [📞] without lifting up the handset.

Adjusting the ringer volume

Press [➕] or [➖] repeatedly to select the desired volume while ringing.

Useful features during a call

Hold

- 1 Press **[Hold]** during an outside call.
- 2 **[↓]**: "Hold" → **[OK]**
- 3 To release hold, press **[↶]**.

Note:

- After holding for 10 minutes, the call is disconnected.

Mute

- 1 Press **[Mute]** during a call.
- 2 To return to the call, press **[Mute]**.

Recall/flash

[R/ECO] allows you to use the special features of your host PBX such as transferring an extension call, or accessing optional telephone services.

Note:

- To change the recall/flash time, see page 24.

For call waiting or Call Waiting Caller ID service users

To use call waiting or Call Waiting Caller ID, you must first subscribe with your service provider/telephone company.

This feature allows you to receive calls while you are already talking on the phone. If you receive a call while on the phone, you will hear a call waiting tone.

If you subscribe to Call Waiting with Caller ID services, the 2nd caller's information is displayed after you hear the call waiting tone on the handset.

- 1 Press **[R/ECO]** to answer the 2nd call.
- 2 To switch between calls, press **[R/ECO]**.

Note:

- Please contact your service provider/telephone company for details and availability of this service in your area.

Temporary tone dialling (for rotary/pulse service users)

Press **[Tone]** before entering access numbers which require tone dialling.

Handset noise reduction

This feature allows you to hear the voice of the person you are talking to clearly, by reducing the surrounding noise coming from the other party's telephone.

Press **[NR]** to turn on/off while talking.

Note:

- Depending on the environment where this handset is being used, this feature may not be effective.
- This feature is not available using the speakerphone.

Handset equalizer

This feature clarifies the voice of the person you are talking to, producing a more natural-sounding voice that is easier to hear and understand.

- 1 Press **[EQ]** while talking.
- 2 **[↓]**: "Equalizer" → **[OK]**
- 3 **[↓]**: Select the desired setting.
- 4 Press **[OK]** to exit.

Note:

- Depending on the condition and quality of your telephone line, this feature may emphasise existing line noise. If it becomes difficult to hear, turn this feature off.
- This feature is not available while using the speakerphone.

Making/Answering Calls

Call share

Available for:
KX-TGE212

You can join an existing outside call. To join the conversation, press **[📞]** when the other handset is on an outside call.

Note:

- To prevent other users from joining your conversations with outside callers, turn the privacy mode on (page 24).

Transferring calls, conference calls

Available for:
KX-TGE212

Outside calls can be transferred or a conference call with an outside party can be made between 2 handsets.

- 1 During an outside call, press **[📞]**.
- 2 **[📞]**: "Intercom" → **[OK]**
- 3 **[📞]**: Select the desired unit. → **[OK]**
- 4 Wait for the paged party to answer.
 - If the paged party does not answer, press **[📞]** to return to the outside call.
- 5 **To complete the transfer:**
Press **[📞]**.

To establish a conference call:

[📞] → **[📞]**: "Conference" → **[OK]**

- To leave a conference, press **[📞]**.
The other 2 parties can continue the conversation.
- To put the outside call on hold: **[📞]** → **[📞]**: "Hold" → **[OK]**
To resume the conference: **[📞]** → **[📞]**: "Conference" → **[OK]**
- To cancel the conference: **[📞]** → **[📞]**: "Stop Conference" → **[OK]**
You can continue the conversation with the outside caller.

Handset locator

You can locate a misplaced handset by paging it.

- 1 **Base unit:** Press **[📞]**.
 - The registered handset beeps for 1 minute.
- 2 To stop paging:
Base unit: Press **[📞]**.
Handset: Press **[📞]**.

Using the Smart Function Key

You can also stop paging by pressing **[NR]**.

Intercom

Available for:
KX-TGE212

Intercom calls can be made between handsets.

Note:

- When paging the handset, the paged handset beeps for 1 minute.
- If you receive an outside call while talking on the intercom, you hear 2 tones. To answer the call, press **[📞]**, then press **[📞]**.

Making an intercom call

- 1 **[📞]** → **[📞]**
- 2 **[📞]**: Select the desired unit. → **[OK]**.
- 3 When you finish talking, press **[📞]**.

Answering an intercom call

- 1 Press **[📞]** to answer the page.
- 2 When you finish talking, press **[📞]**.

Using the Smart Function Key

Press **[NR]** to answer the page.

Turning auto intercom on/off

This feature allows the handset to answer intercom calls automatically when it is called. You do not need to press **[📞]**. When this feature is set to "On", the monitoring handset for the baby monitor feature (page 28) will also answer baby monitor calls automatically. The default setting is "Off".

- [📞]#273**
- [📞]**: Select the desired setting. → **[OK]**
→ **[📞]**

Key lock

The handset can be locked so that no calls or settings can be made. Incoming calls can be answered, but all other functions are disabled while key lock is on.

To turn key lock on, press **[📞]** for about 3 seconds.

- To turn key lock off, press **[📞]** for about 3 seconds.

Note:


- Calls to emergency numbers cannot be made until key lock is turned off.

Power back-up operation

When a power failure occurs, the charged handset temporarily supplies power to the base unit (power back-up mode). This allows you to make and receive calls using a handset during a power failure. The base unit will not perform any other functions. You can program "Power Failure" and the default setting is "Auto" (page 24).

Important:

- If a handset is not placed on the base unit when a power failure occurs, "Base no power Press **[📞]**" or "Press **[📞]**" is displayed. After pressing **[📞]** on the handset, place it on the base unit to start power back-up mode.

- Power back-up mode will not work if the battery level of the power supplying handset is .
- Do not lift the power supplying handset from the base unit during power back-up mode.
- If "Please wait for 1 minute." is displayed, please do not operate the unit until the message disappears.

Panasonic Ni-MH battery performance (supplied batteries) during power back-up mode

When the batteries are fully charged, operating time of the handset in power back-up mode varies depending on usage.

- Continuous use of the handset in power back-up mode: 2 hours max.
- Continuous use the handset other than a handset in power back-up mode: 3 hours max.
- Not in use in power back-up mode: 3 hours max.

Making calls during a power failure

■ When only 1 handset is registered:

- Lift the handset and dial the phone number.
- Within 1 minute, place the handset on the base unit.
 - Wait until speakerphone is turned on automatically and the call is made.
- When the other party answers the call, keep the handset on the base unit and talk using the speakerphone.
- When you finish talking, press **[📞]**.

■ When 2 or more handsets are registered:

You should leave one handset on the base unit for supplying power, and use another handset for making calls.

Note:

- The range of the base unit is limited during a power failure. Please use the handset close to the base unit.

Continuing a call during a power failure

When a power failure occurs during an outside call, the unit informs you with a notification tone. You can continue to talk for about 1 minute.

If you want to continue the conversation, press **[⏏]** and then place the handset on the base unit.

Phonebook

You can add 150 names (16 characters max.) and phone numbers (24 digits max.) to the phonebook, and assign each phonebook entry to the desired category.

Important:

- All entries can be shared by any registered handset.

Adding phonebook entries

- 1 **[OK] → [Menu]**
- 2 **[↓]: "New Entry" → [OK]**
- 3 Enter the party's name. → **[OK]**
 - You can change the character entry mode by pressing **[R/ECO]** (page 34).
- 4 Enter the party's phone number. → **[OK]**
- 5 **[↓]:** Select the desired category. → **[OK]** 2 times → **[Phone]**

Storing a redial list number to the phonebook

- 1 **[Redial]**
- 2 **[↓]:** Select the desired entry. → **[Phone]**
- 3 To store the name, continue from step 3, "Editing entries", page 19.

Storing caller information to the phonebook

- 1 **[→]**
- 2 **[↓]:** Select the desired entry. → **[Menu]**
- 3 **[↓]: "Save CID" → [OK]**
- 4 **[↓]: "Phonebook" → [OK]**
- 5 To store the name, continue from step 3, "Editing entries", page 19.

Categories

Categories can help you find entries in the phonebook quickly and easily. You can

change the names of categories ("Friends", "Family", etc.). By assigning different ringer tones for different categories of callers, you can identify who is calling (category ringer tone), if you have subscribed to Caller ID service.

Changing category names/setting category ringer tone

- 1 **[OK] → [Menu]**
- 2 **[↓]: "Category" → [OK]**
- 3 **[↓]:** Select the desired category. → **[OK]**
- 4 **To change category names**
[↓]: "Category Name" → [OK] →
 Edit the name (10 characters max.). → **[OK]**
To set category ringer tone
[↓]: Select the current setting of the category ringer tone. → **[OK]** → **[↓]:** Select the desired ringer tone. → **[OK]**
- 5 **[Phone]**

Finding and calling from a phonebook entry

- 1 **[Menu]**
- 2 **To scroll through all entries**
[↓]: Select the desired entry.
To search by first character
 - ① Press the dial key **[0]** to **[9]**, or **[#]** which contains the character you are searching for (page 34).
 - ② **[↓]:** Scroll through the phonebook if necessary.**To search by category**
 - ① **[Phone] → [↓]: "Category" → [OK]**
 - ② **[↓]:** Select the desired category. → **[OK]**
 - ③ **[↓]:** Scroll through the phonebook if necessary.
- 3 **[Phone]**

Editing entries

- 1 Find the desired entry (page 19). → **[Menu]**
- 2 **[↓]: "Edit" → [OK]**

Phonebook

- 3 Edit the name if necessary. → [OK]
- 4 Edit the phone number if necessary. → [OK]
- 5 [↕]: Select the desired category (page 19). → [OK] 2 times
- 6 [📞]

Erasing entries

Erasing an entry

- 1 Find the desired entry (page 19). → [🔍]
- 2 [↕]: "Erase" → [OK]
- 3 [↕]: "Yes" → [OK] → [📞]

Erasing all entries

- 1 [🔍] → [🔍]
- 2 [↕]: "Erase All" → [OK]
- 3 [↕]: "Yes" → [OK]
- 4 [↕]: "Yes" → [OK] → [📞]

Chain dial

This feature allows you to dial phone numbers in the phonebook while you are on a call. This feature can be used, for example, to dial a calling card access number or bank account PIN that you have stored in the phonebook, without having to dial manually.

- 1 During an outside call, press [🔍].
- 2 [↕]: "Phonebook" → [OK]
- 3 [↕]: Select the desired entry.
- 4 Press [📞] (right soft key) to dial the number.

Note:

- When storing a calling card access number and your PIN in the phonebook as one phonebook entry, press [⏸] (Pause) to add pauses after the number and PIN as necessary (page 14).
- If you have rotary/pulse service, you need to press [📞] before pressing [🔍] in step 1 to change the dialling mode temporarily to tone. When adding entries to the

phonebook, we recommend adding [📞] to the beginning of phone numbers you wish to chain dial (page 20).

Speed dial

You can assign 1 phone number to each of the dial keys ([1] to [9]) on the handset.

Adding phone numbers to speed dial keys

■ By entering phone numbers:

- 1 Press and hold the desired speed dial key ([1] to [9]). → [📞]
- 2 [↕]: "Manual" → [OK]
- 3 Enter the party's name (16 characters max.). → [OK]
- 4 Enter the party's phone number (24 digits max.). → [OK] 2 times → [📞]

■ From the phonebook:

- 1 Press and hold the desired speed dial key ([1] to [9]). → [🔍]
- 2 [↕]: "Phonebook" → [OK]
- 3 [↕]: Select the desired entry.
- 4 [OK] → [📞]

Note:

- If you edit a phonebook entry which is assigned to a speed dial key, the edited entry does not transfer to the speed dial key.

Editing an entry

- 1 Press and hold the desired speed dial key ([1] to [9]). → [🔍]
- 2 [↕]: "Edit" → [OK]
- 3 Edit the name if necessary. → [OK]
- 4 Edit the phone number if necessary. → [OK] 2 times → [📞]

Erasing an entry

- 1 Press and hold the desired speed dial key (1 to 9). → [⏏]
- 2 [↕]: "Erase" → [OK]
- 3 [↕]: "Yes" → [OK] → [📞]

Viewing an entry/Making a call

- 1 Press and hold the desired speed dial key (1 to 9).
- 2 To make a call, press [📞].

Menu list

To access the features, there are 2 methods.

■ Scrolling through the display menus

- 1
- 2 Press , , , or to select the desired main menu. → **[OK]**
- 3 Press or to select the desired item from the next sub-menus. → **[OK]**
- 4 Press or to select the desired setting. → **[OK]**

■ Using the direct command code

- 1 → Enter the desired code.
Example: Press #101.
- 2 Select the desired setting. → **[OK]**

Note:

- To exit the operation, press .
- In the following table, < > indicates the default settings.
- In the following table, indicates the reference page number.
- Display menu order and sub-menu may vary depending on your model.

Display the menu tree and direct command code table

Main menu: "Time Settings"


Sub-menu 1	Sub-menu 2	Settings	Code	
Set Date/Time*1	—	—	#101	12
Memo Alarm	Alarm1-3	Once Daily Weekly <Off>	#720	26
Time Adjustment*1,*2	—	Caller ID <Manual>	#226	—


Main menu: "Caller List"

Operation	Code	
Viewing the caller list.	#213	32


Main menu: "Intercom"*3

Operation	Code	
Paging the desired unit.	#274	—

Main menu:  "Initial Setup"

Sub-menu 1	Sub-menu 2	Settings	Code	
Ringer Setup	Ringer Volume	Off-6 <6>	#160	—
	Ringtone*4	<Ringtone 1>	#161	—
	Do Not Disturb Mode — On/Off	On <Off>	#238	26
	Do Not Disturb Mode — Start/End	<23:00/06:00>	#237	27
	Do Not Disturb Mode — Ring Delay	30 sec. <60 sec.> 90 sec. 120 sec. No Ringing	#239	27
	Do Not Disturb Mode — Select Category	Category 1-9	#241	27
	First Ring*1,5	<On> Off	#173	—
Time Settings	Set Date/Time*1	—	#101	12
	Memo Alarm — Alarm1-3	Once Daily Weekly <Off>	#720	26
	Time Adjustment*1,2	Caller ID <Manual>	#226	—
Nuisance Call Block*1	Single Number	—	#217	27
	Range of Numbers	—		
	Withheld	On <Off>	#240	28
Speed Dial	—	—	#261	20
Eco Mode*1,6	—	<Off> Eco	#725	13
Security*1,6	—	<Normal> Enhanced	#729	30

Programming

Sub-menu 1	Sub-menu 2	Settings	Code	
Display Setup	LCD & Key Backlight	<On> Off	#276	–
	Contrast (Display contrast)	Level 1–4 <2>	#145	–
	Handset Name	–	#104	30
	Display Name	On <Off>	#105	30
Smart Function Key	–	–	#278	12
Auto Intercom* ³	–	On <Off>	#273	–
Keytones	–	<On> Off	#165	–
Call Restrict* ¹	–	–	#256	30
Auto Talk* ⁷	–	On <Off>	#200	14
Line Setup	Dial Mode* ¹	Pulse <Tone>	#120	13
	Recall/Flash* ^{1,8}	900 msec. 700 msec. 600 msec. <400 msec.> 300 msec. 250 msec. 200 msec. 160 msec. 110 msec. 100 msec. 90 msec. 80 msec.	#121	15
Privacy Mode* ^{1,3,10}	–	On <Off>	#194	–
Base Unit PIN* ¹	–	<0000>	#132	31
Repeater Mode* ¹	–	On <Off>	#138	31
Register	Register Handset	–	#130	39
	Cancel Register* ⁹	–	#131	39
Power Failure	–	<Auto> Off	#152	17
Language	Display	<中文>	#110	12

Main menu: 📞 “Baby Monitor”

Sub-menu 1	Sub-menu 2	Settings	Code	👉
On/Off	—	On <Off>	#268	28
Sensitivity Level	—	Low <Middle> High	#269	29

Main menu: 🎵 “Ringer Setup”

Sub-menu 1	Sub-menu 2	Settings	Code	👉
Ringer Volume	—	Off-6 <6>	#160	—
Ringtone*4	—	<Ringtone 1>	#161	—
Do Not Disturb Mode	On/Off	On <Off>	#238	26
	Start/End	<23:00/06:00>	#237	27
	Ring Delay	30 sec. <60 sec.> 90 sec. 120 sec. No Ringing	#239	27
	Select Category	Category 1-9	#241	27
First Ring*1,5	—	<On> Off	#173	—

*1 If you program these settings using one of the handsets, you do not need to program the same item using another handset. (KX-TGE212)

*2 This feature allows the unit to automatically adjust the date and time each time caller information including date and time is received.
To turn this feature on, select “**Caller ID**”. To turn this feature off, select “**Manual1**”.
(Caller ID subscribers only)

To use this feature, set the date and time first (page 12).

*3 KX-TGE212

*4 The preset melodies in this product (“**Ringtone 3**” - “**Ringtone 40**”) are used with permission of © 2012 Copyrights Vision Inc.

*5 If you do not want the unit to ring before the caller information is received, set to “**Off**”.
(Caller ID subscribers only)

You can only remove the first ring if the unit rings 2 times or more by default, which depends on your service provider/telephone company.

*6 This menu is not displayed when repeater mode is set to “**On**”.

*7 If you subscribe to a Caller ID service and want to view the caller’s information after lifting up the handset to answer a call, turn off this feature.

*8 The recall/flash time depends on your telephone exchange or host PBX. Contact your PBX supplier if necessary.

*9 This menu is not displayed when scrolling through the display menus. It is only available in direct command code.

- *10 To prevent other users from joining your conversations with outside callers, turn this feature on.

Alarm

An alarm sounds at the set time for 1 minute and is repeated 5 times at 5 minute intervals (snooze function). A text memo can also be displayed for the alarm. A total of 3 separate alarm times can be programmed for each handset. You can set one of 3 different alarm options (once, daily, or weekly) for each alarm time.

Important:

- Make sure the unit's date and time setting is correct (page 12).

- 1 **[]#720**
- 2 Select an alarm by pressing **1** to **3**. → **[OK]**
- 3 **[]**: Select the desired alarm option. → **[OK]**

"Off"
Turns alarm off. Go to step 9.

"Once"
An alarm sounds once at the set time.

"Daily"
An alarm sounds daily at the set time. Go to step 5.

"Weekly"
Alarm sounds weekly at the set time(s).

- 4 Proceed with the operation according to your selection in step 3.
 - **Once:**
Enter the desired date and month. → **[OK]**
 - **Weekly:**
[]: Select the desired day of the week and press **[✓]**. → **[OK]**
- 5 Set the desired time. → **[OK]**
- 6 Enter a text memo (10 characters max.). → **[OK]**

- 7 **[]**: Select the desired alarm tone. → **[OK]**
 - We recommend selecting a different ringer tone from the one used for outside calls.
- 8 **[]**: Select the desired snooze setting. → **[OK]**
- 9 **[OK]** → **[]**

Note:

- Press **[]** to stop the alarm completely.
- When the handset is in use, the alarm will not sound until the handset is in standby mode.
- Press any dial key, **[NR]**, or **[]** to stop the sound but keep the snooze function activated.
- If you want to make an outside call when the snooze function is activated, please stop the snooze function before making the call.

Do not disturb mode

Do not disturb mode allows you to select a period of time during which the handset will not ring for outside calls. This feature is useful for time periods when you do not want to be disturbed, for example, while sleeping. Do not disturb mode can be set for each handset. Using the phonebook's category feature (page 19), you can also select categories of callers whose calls override do not disturb mode and ring the handset (Caller ID subscribers only).

Important:

- Make sure the unit's date and time setting is correct (page 12).
- If you have set the alarm, the alarm sounds even if do not disturb mode is turned on.

Turning do not disturb mode on/off

- 1 **[]#238**

- 2 [↕]: Select the desired setting. → [OK]
 - If you select "off", press [📞] to exit.
- 3 Enter the desired hour and minute you wish to start this feature. → [OK]
- 4 Enter the desired hour and minute you wish to end this feature. → [OK] → [📞]

Changing the start and end time

- 1 [📞]#237
- 2 Continue from step 3, "Turning do not disturb mode on/off", page 26.

Setting the ring delay

This setting allows the handset to ring during do not disturb mode if the caller waits long enough. After the selected amount of time passes, the handset rings. If you select "No Ringing", the handset never rings during do not disturb mode.

- 1 [📞]#239
- 2 [↕]: Select the desired setting. → [OK] → [📞]

Selecting categories to bypass do not disturb mode

- 1 [📞]#241
- 2 Select your desired categories by pressing [1] to [9].
 - "✓" is displayed next to the selected category numbers.
 - To cancel a selected category, press the same dial key again. "✓" disappears.
- 3 [OK] → [📞]

Nuisance call block

This feature rejects calls from unwanted callers (Caller ID subscribers only). The following items are available when storing phone numbers in the call block list (50 max.).

- "Single Number": The unit can reject calls from specific phone numbers.
 - "Range of Numbers": The unit can reject calls that begin with a number stored in the call block list, such as a toll-free phone number prefix or certain area codes. You can also set the unit to reject calls that do not have a phone number.
- When a call is received, the unit does not ring while the caller is being identified. If the caller's phone number matches an entry in the call block list, the unit emits no sound to the caller, and disconnects the call.

Important:

- Rejected calls are logged in the caller list.

Storing unwanted callers

Storing a single phone number

Important:

- You must include the area code when storing phone numbers in the call block list.

■ From the caller list:

- 1 [→]
- 2 [↕]: Select the entry to be blocked. → [📞]
- 3 [↕]: "Save CID" → [OK]
- 4 [↕]: "Nuisance Call Block" → [OK]
- 5 [↕]: "Yes" → [OK] → [📞]

■ By entering phone numbers:

- 1 [📞]#217
- 2 [↕]: "Single Number" → [OK]
- 3 [📞] → [↕]: "Add" → [OK]
- 4 Enter the phone number (24 digits max.).
 - To erase a digit, press [C].
- 5 [OK] → [📞]

Storing a range of numbers

- 1 [📞]#217
- 2 [↕]: "Range of Numbers" → [OK]
- 3 [📞] → [↕]: "Add" → [OK]
- 4 Enter the desired number (2-8 digits).
 - To erase a digit, press [C].

5 [OK] → [📞]

Blocking incoming calls that have no phone number

You can reject calls when no phone number is provided, such as private callers.

- 1 [📞]#240
- 2 [📞]: Select the desired setting. → [OK]
- 3 [📞]

Viewing/editing/erasing call block numbers

- 1 [📞]#217
- 2 [📞]: "Single Number" or "Range of Numbers" → [OK]
- 3 [📞]: Select the desired entry.
 - To exit, press [📞].
- 4 **To edit a number:**
[📞] → Edit the number. → [OK] → [📞]
To erase a number:
[X] → [📞]: "Yes" → [OK] → [📞]

Note:

- When editing, press the desired dial key to add, [C] to erase.

Erasing all call block numbers

- 1 [📞]#217
- 2 [📞]: "Single Number" or "Range of Numbers" → [OK]
- 3 [📞] → [📞]: "Erase All" → [OK]
- 4 [📞]: "Yes" → [OK]
- 5 [📞]: "Yes" → [OK] → [📞]

Baby monitor

This feature allows you to listen in on a room where the handset is located, allowing you to easily monitor from different areas of the

house or place. The monitored handset (placed in a baby's room, for example) will automatically call the monitoring handset or the phone number stored when it detects sound.

Important:

- You should perform a test run of the baby monitor procedure to ensure that the baby monitor feature is set correctly. For example, test its sensitivity. Check the connection if you are diverting the baby monitor to an outside line.
- This feature should not be used as a substitute for a medical or caregiver's supervision. It is the caregiver's responsibility to stay close enough to handle any eventuality.

Note:

- If the unit is connected to a PBX system, you cannot set the baby monitor.
- During the monitoring mode, battery consumption is faster than usual. We recommend leaving the monitored handset on the base unit or charger.
- The monitored handset never rings during the monitoring mode.

Setting the baby monitor

Perform the setting operation with the handset to be monitored (for example, the handset placed in a baby's room).

To monitor with a handset

Available for:
KX-TGE212

The internal baby monitor feature is only available between handsets.

- 1 [📞]#268
- 2 [📞]: "On" → [OK]
- 3 [📞]: Select the desired handset number to monitor with. → [OK]
 - "Baby Monitor" will be displayed.
 - The registered handset name/number is displayed.

Note:

- When this feature is on, another handset can hear the monitored handset by making an intercom call.

To monitor from an outside line

■ From the phonebook:

- Press **[F4]** **[#]** **[2]** **[6]** **[8]**
- [↓]**: "On" → **[OK]**
- [↓]**: Select "External" to monitor from an outside line. → **[F4]** → **[F4]**
- [↓]**: "Phonebook" → **[OK]**
- [↓]**: Select the phonebook entry. → **[OK]**
 - "Baby Monitor" will be displayed.

Note:

- If you edit a phonebook entry which is assigned for monitoring, the edited entry does not transfer to the monitor.

■ By entering phone numbers:

- Press **[F4]** **[#]** **[2]** **[6]** **[8]**
- [↓]**: "On" → **[OK]**
- [↓]**: Select "External" to monitor from an outside line. → **[F4]** → **[F4]**
- [↓]**: "Manual" → **[OK]**
- Enter the desired name. → **[OK]**
- Enter the desired number. → **[OK]** 2 times
 - "Baby Monitor" will be displayed.

Note:

- The registered name/number is displayed.

Turning off the baby monitor

The monitored handset cannot be used while baby monitor is set to "On".

- Press **[F4]** on the handset being monitored.
- [↓]**: "On/Off" → **[OK]**
- [↓]**: "Off" → **[OK]** → **[F4]**

Editing an outside monitoring number

- Press **[F4]** on the handset being monitored.
- [↓]**: "On/Off" → **[OK]**
- [↓]**: "On" → **[OK]**
- [↓]**: Select the outside line. → **[F4]**
- [F4]** → **[↓]**: "Edit" → **[OK]**
- Edit the name if necessary. → **[OK]**
- Edit the phone number if necessary. → **[OK]** 2 times

Erasing an outside monitoring number

- Press **[F4]** on the handset being monitored.
- [↓]**: "On/Off" → **[OK]**
- [↓]**: "On" → **[OK]**
- [↓]**: Select the outside line. → **[F4]**
- [F4]** → **[↓]**: "Erase" → **[OK]**
- [↓]**: "Yes" → **[OK]** → **[F4]**

Baby monitor sensitivity

You can adjust the sensitivity of the baby monitor. Increase or decrease the sensitivity to adjust the sound level needed to trigger the baby monitor feature.

- This feature cannot be set during a monitoring call.

- Press **[F4]** on the handset being monitored.
- [↓]**: "Sensitivity Level" → **[OK]**
- [↓]**: Select the desired setting. → **[OK]** → **[F4]**

Answering the baby monitor

■ When monitoring with a handset (KX-TGE212):

Press **[F4]** to answer calls.

If you want to respond from the monitoring handset, press **[F4]**.

Programming

- The monitoring handset will answer calls automatically when the auto intercom feature is set to "On" (page 17).

Note:

- If you receive an outside call when communicating with the monitored handset, you hear 2 tones. To answer the call, press **[📞]**, then press **[📞]**.

■ When monitoring from an outside line:

To answer a call, follow the operation for your phone.

If you want to respond from the monitoring handset, press **[#]1** using tone dialling. You can turn off the baby monitor feature by pressing **[#]0**.

Note:

- 2 minutes after the monitored handset starts a call, communication between the monitored handset and monitoring phone line is turned off automatically.

Other programming

Changing the handset name

The default handset name is "Handset 1" or "Handset 2". You can customise the name of the handset ("Bob", "Kitchen", etc.). This is useful when you make intercom calls between handsets. To display the handset name in standby mode, turn on the handset name display feature (page 30).

- 1 **[📞]#104**
- 2 Enter the desired name (10 characters max.).
- 3 **[OK] → [📞]**

Displaying the handset name

You can select whether or not the handset name is displayed in standby mode. The default setting is "Off".

- 1 **[📞]#105**
- 2 **[👆]**: Select the desired setting. → **[OK]**
→ **[📞]**

Call restriction

You can restrict selected handsets from dialling certain numbers. You can assign up to 6 phone numbers to be restricted, and select which handsets are to be restricted. Storing area codes here prevents the restricted handsets from dialling any phone number in that area code.

- 1 **[📞]#256**
- 2 Enter the base unit PIN (default: "0000").
 - If you forget your PIN, contact an authorised service centre.
- 3 Select the handsets to be restricted by pressing **1** to **6**.
 - All handsets registered to the base unit are displayed.
 - "✓" is displayed next to the selected handset numbers.
 - To cancel a selected handset, press the same dial key again. "✓" disappears.
- 4 **[OK]**
- 5 Select a memory location by pressing **1** to **6**. → **[OK]**
- 6 Enter the phone number or area code to be restricted (8 digits max.). → **[OK]** → **[📞]**

Enhancing security for phone calls

You can increase the security of phone conversations by setting this feature to "Enhanced". When "Enhanced" is selected, **[🔒]** is displayed. The default setting is "Normal".

- 1 **[📞]#729**
- 2 **[👆]**: Selected the desired setting. → **[OK]**
- 3 **[📞]**

Note:

- If you set repeater mode to "On" (page 31):
 - Security is set to "Normal" and **[🔒]** is displayed.

- “Security” is not displayed in the display menu (page 23).
- When enhanced security is enabled, sound may cut in and out during conversations.

Changing the base unit PIN

Important:

- If you change the PIN (Personal Identification Number), please make note of your new PIN. The unit will not reveal the PIN to you. If you forget your PIN, contact an authorised service centre.

- 1 # 1 3 2
- 2 Enter the current 4-digit base unit PIN (default: “0000”).
- 3 Enter the new 4-digit base unit PIN. →
- 4 : “Yes” → →

Increasing the range of the base unit

You can increase the signal range of the base unit by using a DECT repeater. Please use only the Panasonic DECT repeater noted on page 4. Contact your Panasonic dealer for details.

Important:

- Before registering the repeater to this base unit, you must turn the repeater mode on.
- Do not use more than one repeater at a time.

Setting the repeater mode

- 1 # 1 3 8
- 2 : Select the desired setting. → →

Registering the DECT repeater (KX-A405) to the base unit

Note:

- Please use a repeater that has not yet been registered to another unit. If the repeater is registered to another unit, deregister it first,

referring to the Installation Guide for the DECT repeater.

- 1 **Base unit:**
Press and hold for about 5 seconds.
- 2 **DECT repeater:**
Connect the AC adaptor, then wait until the indicator and indicator light green.
- 3 **Base unit:**
To exit the registration mode, press .

Using Caller ID service

Important:

- This unit is Caller ID compatible. To use Caller ID features, you must subscribe to a Caller ID service. Contact your service provider/telephone company for details.


Caller ID features



When an outside call is being received, the caller information is displayed.

Caller information for the last 50 callers is logged in the caller list from the most recent call to the oldest.



- If the unit cannot receive caller information, the following is displayed:
 - “**Out of Area**”: The caller dials from an area which does not provide a Caller ID service.
 - “**Private Caller**”: The caller requests not to send caller information.
- If the unit is connected to a PBX system, caller information may not be properly received. Contact your PBX supplier.

Missed calls

If a call is not answered, the unit treats it as a missed call and  is displayed. This lets you know if you should view the caller list to see who called while you were away.

Even if only one missed call in the caller list is viewed (page 32),  disappears from the display. When you receive another new call,  is displayed again.

Note:

- Even when there are unviewed missed calls,  disappears from the standby display if the following operation is performed by one of the registered handsets:
 - Being replaced on the base unit.
 - Pressing [].

Phonebook name display

When caller information is received and it matches a phone number stored in the phonebook, the stored name in the






phonebook is displayed and logged in the caller list.

Caller list




Important:

- Make sure the unit's date and time setting is correct (page 12).



Viewing the caller list and calling back


- 1 [>]
- 2 Press [] to search from the most recent call, or press [] to search from the oldest call.
- 3 To call back, press []. To exit, press [].


Note:

- If  is displayed in step 2, not all of the information is shown. To see the remaining information, press []. To return to the previous screen, press [].
- If the entry has already been viewed or answered, “✓” is displayed.





Using the Smart Function Key

When  is displayed and the  indicator flashes slowly, there are missed calls.

Press [] in step 1 on “Viewing the caller list and calling back”, page 32.

- “**Missed Call**” must be set to “On” in “Setting the Smart Function Key”, page 12.
- If the handset is placed on the base unit, you need to lift up the handset to view the caller list after pressing [].

Editing a caller's phone number

- 1 [>]
- 2 []: Select the desired entry. → []
- 3 []: “**Edit**” → [OK]
- 4 Edit the number.

5 [↩]

**Erasing selected caller
information**


- 1** [→]
- 2** [↕]: Select the desired entry.
- 3** [X] → [↕]: "Yes" → [OK] → [📞]

Erasing all caller information



- 1** [→]
- 2** [X] → [↕]: "Yes" → [OK] → [📞]

Voice mail service

Voice mail is an automatic answering service offered by your service provider/telephone company. After you subscribe to this service, your service provider/telephone company's voice mail system answers calls for you when you are unavailable to answer the phone or when your line is busy. Messages are recorded by your service provider/telephone company, not your telephone.







When you have new messages,  is displayed on the handset if message indication service is available. Please contact your service provider/telephone company for details of this service.

Important:

- If  still remains on the display even after you have listened to new messages, turn it off by pressing and holding  for 2 seconds.

Character entry

The dial keys are used to enter characters and numbers. Each dial key has multiple characters assigned to it. The characters that can be entered depend on the character entry mode (page 34).

- Press  or  to move the cursor left or right.
- Press dial keys to enter characters and numbers.
- Press  to erase the character or number highlighted by the cursor. Press and hold  to erase all characters or numbers.
- Press  (A→a) to switch between uppercase and lowercase.
- To enter another character located on the same dial key, press  to move the cursor to the next space, then press the appropriate dial key.
- If you do not press any dial key within 5 seconds after entering a character, the character is fixed and the cursor moves to the next space.

Character entry modes

The available character entry modes are Alphabet (ABC), Numeric (0-9), Greek (ΑΒΓ), Extended 1 (ÄÅÄ), Extended 2 (ŠŠŠ), and Cyrillic (АБВ). When in these entry modes except Numeric, you can select which character is entered by pressing a dial key repeatedly.

When the unit displays the character entry screen:

[R/ECO] → : Select a character entry mode. → [OK]

Note:

-  in the following tables represents a single space.

Alphabet character table (ABC)

0	1	2	3	4	5	6	7	8	9	#
0	& ' ()	A B C	D E F	G H I	J K L	M N O	P Q R	T U V	W X Y	#
	* , - .	2	3	4	5	6	S 7	8	Z 9	
	/ 1	a b c	d e f	g h i	j k l	m n o	p q r s	t u v	w x y	
		2	3	4	5	6	7	8	z 9	

Useful Information

Cyrillic character table (АБВ)

0	1	2	3	4	5	6	7	8	9	#
~ 0 1 € I I ÿ	& ' () * , - . / 1	А Б В Г 2	Д Е Ж З 3	И Й К Л 4	М Н О П 5	Р С Т У 6	Ф Х Ц Ч 7	Ш Щ Ъ Ы 8	Ь Э Ю Я 9	#

Error messages


Display message	Cause/solution
Base no power or No link. Reconnect AC adaptor. or No link.	<ul style="list-style-type: none">• The handset has lost communication with the base unit. Move closer to the base unit and try again.• Unplug the base unit's AC adaptor to reset the unit. Reconnect the adaptor and try again.• The handset's registration may have been cancelled. Re-register the handset (page 39).• When "No link." is displayed during a power failure, place a handset on the base unit to supply power to the base unit.
Check Phone Line	<ul style="list-style-type: none">• The supplied telephone line cord has not been connected yet or not connected properly. Check the connections (page 8).
Memory Full	<ul style="list-style-type: none">• The phonebook memory is full. Erase unwanted entries (page 20).• The call block list memory is full. Erase unwanted entries (page 28).
Use rechargeable battery.	<ul style="list-style-type: none">• A wrong type of battery such as Alkaline or Manganese was inserted. Use only the rechargeable Ni-MH batteries noted on page 4, 6.
You must first subscribe to Caller ID.	<ul style="list-style-type: none">• You must subscribe to a Caller ID service. Once you receive caller information after subscribing to a Caller ID service, this message will not be displayed.

Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the base unit's AC adaptor and turn off the handset, then reconnect the base unit's AC adaptor and turn on the handset.

General use


Problem	Cause/solution
The handset does not turn on even after installing charged batteries.	<ul style="list-style-type: none">• Place the handset on the base unit or charger to turn on the handset.

Problem	Cause/solution
The unit does not work.	<ul style="list-style-type: none"> ● Make sure the batteries are installed correctly (page 8). ● Fully charge the batteries (page 8). ● Check the connections (page 8). ● Unplug the base unit's AC adaptor to reset the unit and turn off the handset. Reconnect the adaptor, turn on the handset and try again. ● The handset has not been registered to the base unit. Register the handset (page 39).
The handset display is blank.	<ul style="list-style-type: none"> ● The handset is not turned on. Turn the power on (page 12).
I cannot hear a dial tone.	<ul style="list-style-type: none"> ● Make sure that you are using the supplied telephone line cord. Your old telephone line cord may have a different wiring configuration. ● The base unit's AC adaptor or telephone line cord is not connected. Check the connections. ● Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company.
I cannot use the Smart Function Key even if the  indicator is flashing slowly.	<ul style="list-style-type: none"> ● Another unit is in use. Wait and try again later. ● The key lock feature is turned on. Turn it off (page 17).
I cannot use the intercom feature.	<ul style="list-style-type: none"> ● This feature is available between the handsets. Although the handset displays "Intercom", this feature is not available for single handset models.


Menu list

Problem	Cause/solution
The display is in a language I cannot read.	<ul style="list-style-type: none"> ● Change the display language (page 12).
I cannot activate the eco mode.	<ul style="list-style-type: none"> ● You cannot set eco mode when you set the repeater mode "On". If required, set the repeater mode to "Off" (page 31).
I cannot register a handset to a base unit.	<ul style="list-style-type: none"> ● You entered the wrong PIN. If you forget your PIN, contact an authorised service centre.


Battery recharge

Problem	Cause/solution
The handset beeps and/or  flashes.	<ul style="list-style-type: none"> ● Battery charge is low. Fully charge the batteries (page 8).

Useful Information

Problem	Cause/solution
I fully charged the batteries, but <ul style="list-style-type: none">–  still flashes or– the operating time seems to be shorter.	<ul style="list-style-type: none">• Clean the battery ends (\oplus, \ominus) and the charge contacts with a dry cloth and charge again.• It is time to replace the batteries (page 8).

Making/answering calls

Problem	Cause/solution
 is displayed.	<ul style="list-style-type: none">• The handset is too far from the base unit. Move closer.• The base unit's AC adaptor is not properly connected. Reconnect AC adaptor to the base unit.• The handset is not registered to the base unit. Register it (page 39).• Activating eco mode reduces the range of the base unit in standby mode. If required, turn eco mode off (page 13).
Noise is heard, sound cuts in and out.	<ul style="list-style-type: none">• You are using the handset or base unit in an area with high electrical interference. Re-position the base unit and use the handset away from sources of interference.• Move closer to the base unit.• If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.
The handset does not ring.	<ul style="list-style-type: none">• The ringer volume is turned off. Adjust ringer volume (page 14, 23).• Do not disturb mode is turned on. Turn it off (page 26).
I cannot make a call.	<ul style="list-style-type: none">• The dialling mode may be set incorrectly. Change the setting (page 13).• You dialled a call restricted number (page 30).• The key lock feature is turned on. Turn it off (page 17).

Caller ID

Problem	Cause/solution
Caller information is not displayed.	<ul style="list-style-type: none">• You must subscribe to a Caller ID service. Contact your service provider/telephone company for details.• If your unit is connected to any additional telephone equipment, remove and plug the unit directly into the wall jack.• If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.• Other telephone equipment may be interfering with this unit. Disconnect the other equipment and try again.
Caller information is displayed late.	<ul style="list-style-type: none">• Depending on your service provider/telephone company, the unit may display the caller's information at the 2nd ring or later. Set the first ring to "off" (page 23).• Move closer to the base unit.

Problem	Cause/solution
Time on the unit has shifted.	<ul style="list-style-type: none"> Incorrect time information from incoming Caller ID changes the time. Set the time adjustment to “Manual” (off) (page 23).
The name stored in the phonebook is not fully displayed while an outside call is being received.	<ul style="list-style-type: none"> Edit the phonebook entry name to fit in 1 line of text (page 19).

Liquid damage

Problem	Cause/solution
Liquid or other form of moisture has entered the handset/base unit.	<ul style="list-style-type: none"> Disconnect the AC adaptor and telephone line cord from the base unit. Remove the batteries from the handset and leave to dry for at least 3 days. After the handset/base unit are completely dry, reconnect the AC adaptor and telephone line cord. Insert the batteries and charge fully before use. If the unit does not work properly, contact an authorised service centre.

Caution:

- To avoid permanent damage, do not use a microwave oven to speed up the drying process.

Registering a handset to the base unit

1 Handset:

[] # 1 3 0

2 Base unit:

Press and hold [] for about 5 seconds.

- If all registered handsets start ringing, press [] again to stop, then repeat this step. (KX-TGE212)

3 Handset:

[OK] → Wait until “**Base PIN**” is displayed. → Enter the base unit PIN (default: “0000”).
→ [OK]

- If you forget your PIN, contact an authorised service centre.

Deregistering a handset

1 [] # 1 3 1

- All handsets registered to the base unit are displayed.

2 []: Select the handset you want to cancel. → [OK]

3 []: “Yes” → [OK] → []

Index

- A** Alarm: 26
 - Answering calls: 14
 - Auto intercom: 17
 - Auto talk: 14, 24
- B** Baby monitor: 28
 - Battery: 8, 9
- C** Call restriction: 30
 - Call share: 16
 - Call waiting: 15
 - Call Waiting Caller ID: 15
 - Caller ID service: 32
 - Caller list: 32
 - Caller list edit: 32
 - Category: 19
 - Chain dial: 20
 - Character entry: 34
 - Conference calls: 16
 - Control type: 10
- D** Date and time: 12
 - Dialling mode: 13
 - Direct command code: 22
 - Display
 - Contrast: 24
 - Language: 12
 - Do not disturb mode: 26
- E** Eco mode: 13
 - Equalizer: 15
 - Error messages: 36
- F** First ring: 23
- H** Handset
 - Deregistration: 39
 - Locator: 16
 - Name: 30
 - Registration: 39
 - Hold: 15
- I** Intercom: 16
- K** Key lock: 17
 - Keytones: 24
- M** Making calls: 14
 - Missed calls: 32
 - Mute: 15
- N** Noise reduction: 15
 - Nuisance call block: 27
- P** Pause: 14
 - Phonebook: 19
 - PIN: 31
 - Power failure (power back-up operation): 17
 - Power on/off: 12
 - Privacy mode: 24
- R** Recall/flash: 15
 - Redialling: 14
 - Repeater: 31
 - Ringer tone: 23
- S** Security for phone calls: 30
 - Smart Function Key (NR key): 12
 - Speakerphone: 14
 - Speed dial: 20
- T** Temporary tone dialling: 15
 - Time adjustment: 23
 - Transferring calls: 16
 - Troubleshooting: 36
- V** Voice mail: 34
 - Volume
 - Receiver: 14
 - Ringer (Handset): 14, 23
 - Speaker: 14

For your future reference

We recommend keeping your guarantee card and a record of the following information to assist with any repair under warranty.

Serial No.	Date of purchase
(found on the bottom of the base unit)	
Name and address of dealer	

Attach your purchase receipt here.

Hotline Tel. No.: 2313 0666

Sole Agent for Hong Kong & Macau:

Shun Hing Technology Co., Ltd.

Block B, 9/F., Peninsula Centre 67 Mody Road Tsimshatsui East Kowloon,

Hong Kong

Tel: 2313 0888

Hotline: 2313 0666

Fax: 2368 8068

Email address: shtec@panasonic.oa.hk

Panasonic System Networks Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

© Panasonic System Networks Co., Ltd. 2014



PNQX6387XA

PNQX6387XA CC0614NE2045