

Panasonic "Mini Ice" 冷藏櫃 SCR-S46(EX)-BF / SCR-S66(EX)-BF

注意事項

溫度調校

- 通過產品後底側的溫度旋鈕控制來調節溫度。
 - 1) 平日運作時，請將旋鈕制轉至“NORMAL”位置。
如想調高溫度，請將旋鈕制轉至“WARM”位置。
如想調低溫度，請將旋鈕制轉至“COLD”位置。
 - 2) 如想關閉產品，請將旋鈕制轉至“OFF”位置。

開始啟動

- 取出包裝材料和膠帶，然後將產品保持通風。
- 此產品包裝前已清潔，但建議使用前自行清潔。
- 將電源插頭連接到單相電源插座。
(有關詳細電源資料，請參閱“規格”第12頁)。
- 操作開始約10分鐘後，產品將啟動。
- 在放置物品之前，請操作2小時並冷卻產品內部。

如何擺放物品

- 請將擺放物品放在“LOAD LINE”標記下。
- 如果物品擺放在標記以上，它們會解凍。
(記錄位置標記，顯示在前後內壁上。)
- 請平均放置物品。

從新啟動

- 關機後如需要重新啟動，必須相隔最少5分鐘。
- 如果產品在停機後立即重新啟動，則「過載保護單元」或「接線斷路器」可能跳閘，或者可能對壓縮機施加過大的負載，這將導致故障。

除霜

- 當產品內壁附霜超過5mm時，請進行除霜，以防止冷卻能力下降和影響高效運行。

按照以下步驟有效地除霜

- 1) 取出所有內部物品，並拔出電源插頭。
- 2) 當霜開始溶解時，使用附帶的鏟子處理過量的冰。
(請勿使用鎚、刀或其他利器進行除霜)
- 3) 拔出產品底部的排水塞，將水完全排出。
- 4) 排水完成後，用乾布擦拭產品內部。然後用排水塞塞住出水口。

節約能源

- 為防止冷空氣洩漏，請快速打開和關閉滑門，滑門打開的時間盡可能縮短。
- 請在通風的地方安裝產品，不要阻塞散熱位置。

重要

僅用於顯示和銷售冰和冷凍食品。
不要存放下面列出的食品。
如果需要儲存，它們必須密封。
下面的食品會產生特別強的腐蝕性氣體，這會引起麻煩。
它們必須密封或包裹在用於食品的塑料包裝中。
同樣，任何其他食品必須密封並標示清楚。

- 預煮食品，麵包麵團和其他含有醋酸和酵母的食物或沙拉和調味品。
- 豆類和豆類加工食品。
- 熟蛋或煎蛋，和其他加工的蛋製品。

注意事項

To prevent any accident happen, please avoid children to use it alone.
為免產生意外，請避免兒童單獨使用此產品。



When the product initially starts, the temperature on front side machine will be slightly high. This is a normal phenomenon, and it will be gradually declined after 24 hours' operation.

產品首次啟動時，機身正面溫度會稍高，此乃正常現象。而高溫將於約24小時後逐漸下降。

In case of any inconsistency between the English version and Chinese version, the English version shall prevail.
如英文版與中文版的內容不一致，以英文版為準。

 信興科技有限公司

查詢熱線：2313 0666
網址：www.panasonic.oa.hk